INDEX

--A--

accessory items, 2-4
audible alarm, 1-13, 3-1, 3-2, 3-10, 3-11
audio jack cable, 2-4
Automatic Bad Block Assignment, A-12

--B--

background rebuilding, A-12
Bad Block Handling in Degrade Mode, A-10
BBU, 1-2, 1-5, 1-8, 2-6, 4-14, 5-2, 5-3
block striping, A-3

--C--

cache coherency, 1-2
capacity, 2-11
component check, 2-1
controller module, 1-3, 1-8, 2-10, 5-1, 5-2
controller, A-2
cooling fan module, 1,-3, 1-5, 1-11, 3-9, 5-1, 5-7

--D--

DIMM module, 2-5, 5-2, 5-3
disk failure, A-3, A-4, A-9
disk mirroring, A-4
disk spanning, A-8
dongle kit, 1-7, 5-9
drive bay, 1-4, 1-7, 2-11
drive ID, 1-7
drive tray, 2-11, 2-16, 4-14, 5-1
driveplane, 1-3, 1-8
dual active, 1,-2, 1-10, A-10
dual data paths, A-10
dual redundant, 1-2

--E--

ECC checking., 2-5
ESD, 2-1, 2-2
ethernet port, 1-10, 3-9
expansion port, 1-10

--F--

fabric switch, 4-3
failback, A-10
failed drive, A-11
failover software, 4-4
failover, 1-2, A-10
FC, 4-1
FC-AL, 4-3, A-2
fibre switch, 4-6, 4-8, A-2
firmware, 1-13, 3-1, 3-2
front flap, 2-16, 2-17
front panel, 1-3, 1-4

--G--

Generic Operation Manual, 3-2, 3-11

GUI, 1-13, 3-1

--H--

hard drive, 2-2, 2-11, 4-14, 5-1, 5-9,
HBA, 4-4, A-2
host redundancy, 4-5, 4-8
hot-swap mechanism, 1-3
hot-swappable, A-11

--I--

I^2C bus, 1-12, 3-12
Intelligent drive handling, A-11

--J--

JBOD, A-2

--L--

laser, 4-1, 4-2
LC connector, 4-2
LCD panel, 1-4, 1-6, 3-1, 3-6, 4-16
LED, 1-12, 3-1
lower level, 2-3
LUN Masking, A-12
LUN, A-12

--M--

Media Scan, A-10
memory module, 2-1, 2-5, 4-13
midplane, 1-3
mini-SCSI connector, 1-9
modular, A-13
multi-path topology, 4-9
multiple-block striping with distributed parity, A-7
MUX kit, 1-8, 5-9

--N--

non-OFC, 4-2
NPC, 3-1, 3-10

--O--

OFC, 4-2
optical cables, 4-1

--P--

parity, A-6
PATA drive, 2-11, 2-14
PATA, 1-7
path redundancy, 4-5, 4-6
points of failure, 4-4
point-to-point, 4-3, A-2
power cable, 2-4, 4-14
power down, 4-17
power on, 4-13
power switch, 1-3, 1-5, 1-10, 4-15
pre-installed components, 2-3
primary controller, 1-6, 4-11
PSU, 1-3, 1-5, 1-10, 3-8, 5-1, 5-5

--R--

RAID 0, A-3
RAID 1(0+1), A-5
RAID 1, A-4, A-5
RAID 3, A-6
RAID 5, A-7, A-8

RAID level, A-2
RAIDWatch User's Manual, 2-4, 3-10
RAIDWatch, 1-13, 3-1, 3-9, 3-10
RCC channel, 1-9
rear panel, 1-3, 1-4, 1-5, 1-10
redundancy, A-2, A-3, A-9
redundant controller, 1-6
Regeneration of parity, A-12
remote management, 1-10
RJ-45 port, 1-10
RS-232C (Audio Jack) serial port, 1-10

--S--

S.M.A.R.T, A-12
SATA drive channel, 1-9
SATA drive, 2-11, 2-12, 2-14
SATA, 1-7
SATA-to-PATA dongle kit, 2-12
SATA-to-PATA MUX kit, 2-12
SATA-to-PATA, 2-1
SATA-to-SATA MUX kit, 2-12
SATA-to-SATA, 2-1
SDRAM DIMM, 2-4
secondary controller, 1-6
SFP connector, 1-9, 4-1
SFP transceivers, 2-2
SFP, 4-2
single controller, 1-2, 1-7, 5-2
single host, 4-4
spares, A-9, A-11
speed auto-detection, 1-9
startup, 4-17
static free, 2-1

--T--

terminal emulation program, 1-13

--U--

unpacking, 2-1
upper level, 2-3
UPS, 1-10

--V--

Verify-after-Write, A-12

This page is intentionally left blank