Appendix E

Spare Parts and Accessories

E.1 Overview

All the active components in the EonStor subsystem can be replaced. If any of these components fail then they can, if configured in a fully redundant mode, be hot-swapped. The different spare parts for the EonStor subsystem can be ordered separately. This Appendix lists the model names for the different spare parts and accessories. If you need to order individual parts please use these model names.

E.2 Spare Parts

The active components and their model names are listed in the table below.

E.2.1 General Spare Parts

The spare parts shown in the table below are common to all the models described in this series.

Model Name	Description
IFT-9270CDTray	HDD Tray

IFT-9270CPSU	Power Supply Unit
IFT-9270CFanMod	Cooling FAN Module
IFT-9270CLCDMod	2 x 16 Front Panel LCD module
IFT-9270CLCDPan	LCD Front Panel
IFT-9270CEncBrkL	Left bracket for mounting a 3U enclosure into a cabinet.
IFT-9270CEncBrkR	Right bracket for mounting a 3U enclosure into a cabinet.
IFT-9270CHandLNL	Front Panel left handle
IFT-9270CHandR	Front Panel right handle
IFT-9270CPSW	Power Switch Module

E.2.2 Single Controller Spare Parts

The spare parts shown in the table below are only used for the single controller models.

Model Name	**Description**
IFT-9270AFGCM	Dual host 2Gb FC-to-SATA Controller Module for single controller subsystems
IFT-9270AUGCM	Dual host SCSI-to-SATA Controller Module for single controller subsystems

IFT-9270AN1S1P	SATA-PATA Dongle Board for Single models
IFT-9270ADT1S1P	HDD Tray pre-installed SATA-to-PATA dongle board for Single controller subsystems
IFT-7260S-16F2D	Dual host 2Gb FC-to-SATA controller for single controller Suma subsystems
IFT-7260S-16U3D	Dual host SCSI-to-SATA controller for single controller Suma subsystems

E.2.3 Redundant Controller Spare Parts

The spare parts shown in the table below are only used for the single controller models.

Model Name	**Description**
9270AFCRM	Dual host 2Gb FC to SATA Redundant Controller Module
IFT-9270AN2S1S	SATA-to-SATA MUX Board for Redundant controller subsystems
IFT-9270ADT2S1S	HDD Tray with pre-installed SATA-to-SATA MUX Board for Redundant controller subsystems
IFT-9270AN2S1P	SATA-to-PATA MUX Board for Redundant controller subsystems

IFT-9270ADT2S1P	HDD Tray with pre-installed SATA-to-PATA MUX Board for Redundant controller subsystems
IFT-7260R-16F2D	Dual 2Gb FC to SATA Redundant Controller

E.3 Accessories

The accessories and their model names are listed in the table below.

Model Name	**Description**
IFT0-9270ABT	BBU Module
IFT-9011	Null Modem
9270ASCab	RS-232C serial cable, audio Jack to DB-9 Cable for FW download

APPENDIX E: SPARE PARTS AND ACCESSORIES E-1

E.1 OVERVIEW E-1
E.2 SPARE PARTS E-1
E.3 ACCESSORIES.....E-3